



## Double Log Swing Assembly Instructions

Please read and understand the complete instructions prior to assembly and use of swing.

Customer agrees to hold Dundalk LeisureCraft Inc. and any of its authorized dealers free of liability for improper installation, maintenance and repair of this product.



## Before you begin you'll need:

A rubber mallet

A  $\frac{9}{16}$ " socket wrench.

A second person to help you hold parts while you fasten them. (recommended)

Read instructions thoroughly. Make sure you understand and plan for all steps before starting.

## Assemble frame as shown.

1. Bottom Rail → Corner Posts.
2. One [Bottom Rail / Corner Posts] → Top Rails Assembly
3. [Bottom Rail / Corner Posts / Top Rails Assembly] → The other [Bottom Rail / Corner Posts]
4. Side Braces → Corner Posts using Lag Screws, as shown.
5. Corner Braces → Corner Posts and Bottom Rails with Lag Screws. (See previous picture on pg. 1)





## Hang the Swing Seat Assemblies



## Fasten the Platform



# Congratulations, you have successfully assembled your Double Log Swing!

## WARRANTY

Our Products are warranted to be free of defects in materials and workmanship under normal use and service, for a period of three years (3 Years) from date of purchase. With the warranty you will get a NO HASSLE next business day (depending on shipping service) replacement for all requested parts. Product must be cared for properly, this warranty does not cover misuse or negligence and the manufacturer is not liable for any injury or damage caused by the product. The warranty is also not valid if repairs are attempted by anyone not authorized to do so. Please contact your Dundalk LeisureCraft Dealer for more warranty Information.

## SAFETY

A few simple precautions can help keep everyone swinging safely:

- Always sit in the swing. Don't stand or kneel on the seat or platform.
- Hold on tightly while swinging, and when finished, make sure the swing comes to a complete stop before getting off.
- Stay a safe distance from the swings while in use, being careful not to run or walk in front of or in back of moving swings.

## MAINTAINING YOUR SWING

If you decide to stain your swing the process will have to be repeated every 2 or 3 year's depending on the elements it is in.

If you decide to leave your swing natural, it will weather off to a rustic silver grey look. It is built with cedar and made to weather the elements.

Check the hardware periodically to make sure it doesn't work loose with usage over time.

Contact your local dealer or Dundalk LeisureCraft Inc. directly if you have further questions or concerns regarding your product.

Manufacturer:

Dundalk LeisureCraft Inc  
318448 8th Line NE  
Melancthon, Ontario Canada  
L9V 2K3

Phone: (888) 923-9813

Email: [infor@dundalkleisurecraft.com](mailto:infor@dundalkleisurecraft.com)

Website: (Canada) [www.dundalkleisurecraft.com](http://www.dundalkleisurecraft.com)

Website: (USA) [www.leisurecraftusa.com](http://www.leisurecraftusa.com)