



Log Futon Assembly Instructions

Thank you for purchasing our Canadian-made products.



Please read and understand the instructions prior to assembly. Customer agrees to hold Dundalk LeisureCraft Inc. and any of its authorized dealers free of liability for improper installation, maintenance or repair of this product.

Tools Required:

- 1/2" and 5/8" wrenches (or adjustable)



2. Fasten Half Log Stretchers to Arms:

- Insert 1"-long bolts into the holes in the brackets on the half-log Stretchers, leaving enough room to hook them over the brackets from the previous step.
- Hook the protruding bolt heads through the bracket slots as shown and tighten the bolts with a wrench.



1. **Fasten 4 Brackets to Posts** with the eight 1 1/4" lag screws into predrilled holes.



3. **Fasten Hinges** with 1 1/4" Lag Screws on the bottom side rail into pre-drilled holes.

- There are left and right hinges.
- The holes to fasten the brackets to the arm are toward the back of the arm.
- The spring is toward the front of the futon.



4. **Attach the back deck** first by lining up the holes in the deck to the holes in the hinge.

- The Back Deck has NO Gripper Pad.
- Insert the 3 1/2" bolts from the top with washers on the top and nuts on the bottom of the deck.
- Make sure the slat-support piece is facing down (slats are level with frame when installed)



5. **Repeat the process for the front deck.** (this one has the gripper pad)

Your Log Futon Frame is now assembled.

Video: www.youtube.com/embed/ftayomhmq3c

Note: Bolts should be tightened periodically to ensure a long-lasting Futon.

Please contact retailer for warranty claims

Thank you for your purchase!

Manufactured by: Dundalk LeisureCraft Inc.
318448 8th Line N.E., Melancthon, ON L9V 2K3
Phone: (888) 923-9813

Web: www.dundalkleisurecraft.com
Email: info@dundalkleisurecraft.com